

THE PURIFIER FOR HEALTHCARE PROVIDERS

# ISOLATION, PARTICLE ABATEMENT UV OPTION FOR ANTIGEN AND PATHOGEN STERILIZATION

THE AIRPURA 1600 Available in White / Black / Cream

THE AIRPURA LIMITED WARRANTY
5 years parts / 10 years labor



## THE AIRPURA 1600 SPECIALLY DESIGNED FOR USE IN HEALTHCARE CLINICS AND INSTITUTIONS.

- HEPA FILTER CLOSE ENDED METAL CAPPED that captures 99.97% of particles as small as 0.3 microns
- TITANCLEAN™ TITANIUM DIOXIDE (TIO2)
   COATING IN CONJUNCTION with the UV light,
   creates an oxidizing process that instantly
   breaks molecular bonds and reduces airborne
   chemicals to smaller safer compounds, until only
   carbon dioxide and water vapor are left.
- Effective for up to 2000 SQUARE FEET.
   Provides a complete air exchange every 30 minutes.


- OPTIONAL NEGATIVE AIR ACCESSORIES AVAILABLE. Enables you to quickly create an isolation area.
- SOLID EASY TO MOVE, LOCKABLE CASTERS.
   Weighs less than 30 lbs. Moves easily and
   casters can be locked in place.

# HIGH QUALITY HEPA FILTER

Over 100 square feet of filtration surface with 3" deep folds.

The Hepa is warm rolled to avoid cracking at the folds and avoid leakage.


Spacers keep the folds open and make sure that all the surface area is filtering.







### **FILTRATION SYSTEM**



## **UNIQUE FEATURES**

**PRESSURE SEAL** Airpura's unique pressure seal on the filter chamber ensures that all of the dirty air passes through the filters. Other systems allow leakage and do not achieve the 99.97% HEPA filtration rating.

**FELT GASKETS** seal the filter chamber. Maximize filtration with no rubber off-gassing found with other filters.

**BACKWARD CURVED MOTORIZED IMPELLER** eliminates the vibrations and noise associated with older motor and shaft set ups

**VARIABLE SPEED MOTOR** lets you choose your ideal level of filtration.

**MOTOR OUT OF THE AIR FLOW.** Most air purifiers blow the clean air over the motor and pick up fresh impurities

**UNIMPEDED AIRFLOW** simple and direct internal airflow avoids the air turbulence, inefficiency and noise associated with more convoluted systems

**SEPARATE ELECTRICAL PARTS CHAMBER** prevents any off gassing from capacitors, condensers or switches.

**PERFORATED STEEL EXTERIOR** offers both a softer appearance and 360 degree air intake and distribution.

## TECHNICAL SPECIFICATIONS

#### **PARTICLE REMOVAL**

Over 100 sq ft true HEPA (Measured only 1 side) 10 pleats per inch Pleats warm rolled with separators

#### **AIR FLOW 560 CFM**

More cfm than any other portable unit available

#### **PRE-FILTER**

570 sq in x 1 in

#### **HOUSING**

Powder coat steel

#### SIZE

23" x 15"

#### WEIGHT

29 lbs total

#### **VOLTAGE OPTIONS**

115 or 220 volts

#### **WATTS**

120 on high / 40 on low

#### **SOUND LEVEL**

28.1 db on low (at 6 feet) 62.3 db on high (560 cfm) (Room level 25.1 db)

#### **ETL CERTIFIED**

Conforms to ANSI / UL 507

YOUR		
AIRPURA™	DEAL	ER